

Checklists for Operations

Within the Washington D.C. and New York ADIZ Areas

<p>VFR traffic pattern operations within the ADIZ</p> <p>On the ground:</p> <ul style="list-style-type: none">• File and activate flight plan with FSS (VFR or IFR)• Obtain discrete code from FSS or ATC via clearance delivery or landline• Transponder ON squawking code <p>In the air:</p> <ul style="list-style-type: none">• Monitor CTAF (NO ATC COMMUNICATION REQUIRED)• Do NOT leave the airport vicinity without ATC approval and radio contact• Maintain your discrete code until you have landed or are outside the ADIZ boundary <p>CLOSE Flight Plan after landing</p>	<p>VFR flights desiring entry into the ADIZ area</p> <p>Before Penetrating the ADIZ:</p> <ul style="list-style-type: none">• File and activate flight plan with FSS (VFR or IFR)• Contact ATC and obtain transponder code <p>While operating within the ADIZ:</p> <ul style="list-style-type: none">• Maintain two-way communications with ATC while operating within the ADIZ• Maintain your discrete code until you have landed or are outside the ADIZ boundary <p>• To enter the Class B airspace area within the ADIZ, pilots must obtain a Class B clearance *</p> <p>CLOSE Flight Plan after landing</p>
<p>VFR flights from airports within the ADIZ (XC, practice area outside ADIZ)</p> <p>On the ground:</p> <ul style="list-style-type: none">• File and activate flight plan with FSS (VFR or IFR)• Obtain discrete code from FSS or ATC via clearance delivery or landline• Transponder ON squawking code <p>Before becoming airborne:</p> <ul style="list-style-type: none">• Establish two way communications with ATC prior to departing towered airports (nontowered airports, establish prior to departing the airport traffic area) <p>After becoming airborne:</p> <ul style="list-style-type: none">• Maintain two-way communications with ATC while operating within the ADIZ.• Follow ATC instructions until outside the ADIZ boundary• Maintain your discrete code until you have landed or are outside the ADIZ boundary <p>CLOSE Flight Plan after landing</p>	<p>IFR operations within the ADIZ</p> <p>On the ground:</p> <ul style="list-style-type: none">• File and activate flight plan with FSS (VFR or IFR)• Obtain discrete code from FSS or ATC via clearance delivery or landline• Transponder ON squawking code <p>Before becoming airborne:</p> <ul style="list-style-type: none">• Establish two way communications with ATC prior to departing towered airports (nontowered airports, establish prior to departing the airport traffic area) <p>After becoming airborne:</p> <ul style="list-style-type: none">• Maintain two-way communications with ATC while operating within the ADIZ.• Maintain your discrete code until you have landed or are outside the ADIZ boundary <p>CLOSE Flight Plan after landing</p>
<p>REMEMBER:</p> <p>While operating within the ADIZ:</p> <ul style="list-style-type: none">• Maintain two-way communications with ATC while operating within the ADIZ• Maintain your discrete code until you have landed or are outside the ADIZ boundary	<p>REMEMBER:</p> <p>Before entering Class B, C or D airspace:</p> <ul style="list-style-type: none">• Pick up a separate clearance to enter Class B airspace, or establish two-way radio contact with a Class C or D tower• Close flight plans after landing